Instructions for disassembly and assembly of bulldog saddlebags for Suzuki intruder m109r



!!! Warning !!!

-We are not responsible for all errors and damages caused by unprofessional work.

- All rights reserved. Design of saddlebags are subject to copyright and other intellectual property laws. They may not be copied, altered or used on other websites for trading or reproduction purposes.
- When assembling, follow the same procedure as for disassembly. That is, the hinge pads and pads under the lock guide may differ in. counts on the left and right saddlebag due to the different thickness of the material.

Disassembly - preparation before spraying.

1.Step

Removing hinges (Imbus key 3mm)







loosen the 3mm Imbus screws



rubber seal



remove rubber plugs



remove the 3mm Imbus screw

2.Step

Disassembly of the lock **! warning !** left lock for left saddle bag, right lock for right saddle bag





Imbus key 3mm



The washer determines the movement of the tongue (the left lock has the left position and the right lock the right one!. lock right!.)

right lock "R"

left lock "L"





Remove the metal washer



Remove the silicone pad from the bottom and top.

Loosen the 22mm nut

3.Step Removing the guide pad



guide pad





Guide guides (adjust the height of the guide)



left saddlebags "L"



rights saddlebags "R"

4.Step Removing rubber seal



rubber seal



Spraying : leave to a professional

! Warning ! recommended drying temperature in the spray booth max40 ° C

Assembly after painting

1.step

Installation of interior carpet

2.step





Installation of rubber seals



hinge assembly





cap assembly

5.step



lock assembly

6.Step

Stick the label on the inside of the cap



information

7.Step

Sticking self-adhesive fabric on the inside of the saddelbags



8. Step

Glue the pressure self-adhesive seal



9.Step Remove the rear fender screws





The screws must be replaced with longer ones that are in the package

!!! Warning !!!

We are not responsible for all errors and damages caused by unprofessional work.

Materials in the package

- rubber screw covers. 8pz
- carpets 2pz
- spare screws for attaching the trunk 8x70 (2pz), 8x90 (2pz)
- felt on the inside 2pz
- replacement upper washers for regulating the height of the lock stop (2pz)
- Outer seal 2x 60cm. 2 pz
- instruction 1pz
- stickers 2pz